

<u>LOCATION NO.</u>	<u>DRAWING NO.</u>	<u>REV.</u>	<u>DETAIL NAME</u>	<u>DRAWING STATUS</u>
---------------------	--------------------	-------------	--------------------	-----------------------

T-51 INTRODUCTION INDEX

			Titan T-51 Owner Sheet	
	DOC. #13	B	Tools Brief	
	DOC. #14	B	Construction Brief	
	DOC. #2	A	Build Guideline	
	DOC. #1	A	T-51 Assembly	
INT. 1	T51-05-INS-1148	A	Orthographic View	A
			Fuselage Station Overview	
INT. 2	T51-02-ADV-0176	A	Side View of T-51	P
INT. 3	T51-02-ADV-0177	A	Top View of T-51	P
INT. 4	T51-02-ADV-0178	A	Wing Spar Layout	P
			Wing & Center Section ISO	
INT. 5	92-INS-0198	A	Hardware Identification	A

T-51 FUSELAGE INDEX

	DOC. #3	A	Fuselage Section	
	DOC. #4	A	Tail Section Assembly	
	DOC. #8	A	Hat Sections, Bulkheads & Cowling Stringers	
F0.5	T51-09-INS-1847	A	Fuselage Halves Mating Instructions	A
F1	T51-05-INS-1161	B	Hat Section Installation Ins.	A
F2	T51-03-INS-0818	E	Upper & Lower Bulkhead Locations	A
F3	T51-03-INS-0963	C	Hat Section & Stringer Layout	A
F4	T51-07-INS-1606	B	Station #5/Instrument Panel Installation	A
F5	T51-04-INS-1041	E	Station #3 Installation	A
F6	T51-03-INS-0820	D	Center Bulkhead #3 Ins.	A
F7	T51-04-INS-1053	E	Fuselage Former - Station #2 Ins.	A
F8	T51-06-INS-1487	D	Firewall Installation Ins.	A
F9	T51-08-INS-1711	C	Suzuki Firewall Layout Template	A
F10	T51-03-INS-0956	B	Fuselage Upper Cowling Stringer Location	A
F11	T51-03-INS-0811	E	Rudder & Elevator Bellcrank Assembly	A
	DOC. #9	A	Fuselage Skins	
F12	T51-04-INS-1087	A	Skin Attachment Ins.	A
F13	T51-03-INS-0944	C	Fuselage Skin Location	A
F14	T51-05-INS-1175	B	Skin Attachment Ins.	A
F14.1	T51-08-INS-1786	A	Turtle Deck Installation	A
F15	T51-06-INS-1401	B	Mini Merlin Fwd Baggage Door Installation	A
F16	T51-03-INS-0960	D	Windscreen Trim Installation	A
F17	T51-05-INS-1319	B	Fwd Skins Installation Ins.	A
	DOC. #10	A	Inner Cockpit Panels	
	DOC. #16	A	Bulkhead #3 Supplemental	
F18	T51-03-INS-0945	F	Inner Cockpit Panels	A

<u>LOCATION NO.</u>	<u>DRAWING NO.</u>	<u>REV.</u>	<u>DETAIL NAME</u>	<u>DRAWING STATUS</u>
F19	T51-04-INS-1052	F	Inner Cockpit Panel Mounting Ins.	A
F20	T51-03-INS-0893	D	Fwd Rudder Pedal Installation	A
F21	T51-03-INS-1005	F	Master Brake Cylinder Installation	A
F22	T51-06-INS-1325	B	Center Pedestal Ins.	A
F23	T51-04-INS-1000	B	Coolant Line Routing Ins.	A
F24	T51-04-INS-1096	B	Rudder Pedal Carriage Release Ins.	A
F25	T51-03-INS-0971	C	Fwd Baggage Door Ins.	A
F26	T51-03-INS-0950	D	Fuselage Cowling Flange & Skin Location	A
	DOC. #11	A	Canopy Installation	
F27	T51-04-INS-1037	E	Cockpit Skin Sectional	A
F28	T51-07-INS-1681	B	Inner Hoop Panel/Outer Side Skins Installation	A
F29	T51-03-INS-0649	E	Canopy Track Installation	A
F30	T51-07-INS-1634	D	Canopy Lock Installation	A
F31	T51-07-INS-1633	F	Canopy Hoop & Tracks	A
F32	T51-07-INS-1607	C	Canopy Skirt & Hoop Installation	A
F32.5	T51-09-INS-1808	A	Horizontal Stabilizer Placement	A
F33	T51-03-INS-0822	F	Horizontal Main Spar Carrythru Installation	A
F34	T51-03-INS-0821	I	Horizontal Stabilizer Ins.	A
F35	T51-03-INS-0844	C	Horizontal Stabilizer Installation - Aft	A
F36	T51-03-INS-0937	C	Horizontal Stabilizer Installation - Fwd	A
F37	T51-05-INS-1141	D	Horizontal Stabilizer Skins	A
F38	T51-03-INS-0828	D	Vertical Stabilizer Installation	A
F39	T51-04-INS-1011	C	Belly Stringer Installation (Aluminum)	A
F39.1	T51-09-INS-1809	B	Radiator Top Plenum Installation	A
F40	T51-05-INS-1130	B	Fwd Radiator Plenum Ins.	A
F41	T51-06-INS-1485	B	Radiator Installation (Rotax)	A
F42	T51-03-INS-0901	D	Radiator Exhaust Installation (Rotax)	A
F43	T51-07-INS-1682	E	Radiator Exhaust Installation (V6 Only)	A
	DOC. #12	B	Rear Fuselage Skins	
F44	T51-03-INS-0977	C	Aft Baggage Door Ins.	A
F45	T51-06-INS-1407	D	Tailwheel Enclosure Ins.	A
F46	T51-06-INS-1406	C	Aft Push Tube Ins.	A
F47	T51-03-INS-0929	E	Flap Driver Installation	A
F48	T51-03-INS-0890	F	Front/Rear Seat Installation	A
F48.1	T51-09-INS-1814	A	Seat Pan Installation	P
F49	T51-06-INS-1477	A	Longeron Extension Ins.	A
F50	T51-08-INS-1764	A	Nose Bowl/Spinner Installation	A

T-51 WING INDEX

	DOC. #5	A	Wing Assembly	
W0.5	T51-09-INS-1849	A	Center Section & Wing Matting Instructions	A

<u>LOCATION NO.</u>	<u>DRAWING NO.</u>	<u>REV.</u>	<u>DETAIL NAME</u>	<u>DRAWING STATUS</u>
W1	T51-02-INS-0385	G	Outer Wing Panel Rib Drill Patterns	A
W2	T51-02-INS-0386	D	Outer Panel Rib Installation	A
W3	T51-02-INS-0388	B	Stringer, Stub Rib & Intermediate Web Ins.	A
W4	T51-02-INS-0387	F	Aft Spar Rivet Locations & Fitting Installation	A
W5	T51-02-INS-0544	C	Aileron Bellcrank Assembly Installation	A
W5.5	T51-09-INS-1841	A	Internal Wing Tank Installation	P
W6	T51-02-INS-0545	B	Pitot Tube Installation	A
W7	T51-07-INS-1659	D	External Fuel Tank Hard Point Ins.	A
W8	T51-02-INS-0546	C	Upper Wing Skin Installation	A
W9	T51-02-INS-0541	D	Fitting & Clecoing Lower Skin	A
W10	T51-02-INS-0542	E	Flap Bracket Slot Layout (Early)	A
W11	T51-02-INS-0499	D	Flap Stub Rib Installation (Early)	A
W12	T51-02-INS-0543	D	Flap Bracket Stub Ribs & Flap Bracket Ins. (Early)	A
W13	T51-02-INS-0547	C	Wing Inspection Layout	A
W14	T51-02-INS-0558	B	Upper & Lower Skin Rivet Callout	A
W15	T51-03-INS-0601	A	Wing Skin D-Cell Final Installation	A
W16	T51-05-INS-1292	C	Mounting Wing Deflector Ins.	A
W17	T51-07-INS-1658	A	External Fuel Tank Assembly Ins.	P

T-51 CENTER SECTION INDEX

	<u>DOC. #6</u>			
		A	Center Section Assembly	
CS1	T51-03-INS-0645	A	Fuel Tank Foam Saddle Cut	A
CS2	T51-03-INS-0610	B	Fuel Tank Bay Lower Foam Installation	A
CS3	T51-03-INS-0609	C	Top View of Fuel Tank Bay	A
CS4	T51-05-INS-1156	B	Center Tank Ins.	A
CS5	T51-07-INS-1631	E	Center/Main Fuel Tanks Line Routing	A
CS6	T51-03-INS-0611	B	Fuel Tank Plumbing Installation	A
CS7	T51-04-INS-0995	A	Fuel Line Routing Ins. for Rotax 912	A
CS8	T51-04-INS-0996	D	Fuel Line Routing Ins. for Rotax 912/F.I. Engines	A
CS9	T51-04-INS-0992	A	Pitot Tube & Static Pressure Ins.	A
CS10	T51-04-INS-1043	D	Wing Walkway Stiffener Ins.	A
CS11	T51-03-INS-0927	C	Up Switch Bracket Installation	A
CS12	T51-03-INS-0928	C	Down Limit Switch Bracket Installation	A
CS13	T51-03-INS-0650	F	Inboard Flap Bracket Installation (Early)	A
CS14	T51-03-INS-0604	C	#4 Rib Flange Installation	A
CS15	T51-03-INS-0603	A	Center Section L.E. Foam Installation	A
CS16	T51-04-INS-1089	B	Fuel Filler Neck Attachment Ins.	A
CS17	T51-08-INS-1713	C	Aft Rudder Pedal Foot Well Installation	A
CS18	T51-03-INS-0602	A	Wing Skin Trim Ins.	O
CS18.5	T51-09-INS-1848	A	Center Section & Fuselage Mating Instructions	A
CS19	T51-03-INS-0991	C	Wing Root Fairing Ribs, Webs & Bracket Locations	A

<u>LOCATION NO.</u>	<u>DRAWING NO.</u>	<u>REV.</u>	<u>DETAIL NAME</u>	<u>DRAWING STATUS</u>
CS20	T51-03-INS-0961	C	Wing Fairing Location	A
CS21	T51-03-INS-0962	F	Lower Fairing Skins & Access/Inspection Panel Location	A
CS22	T51-09-INS-1813	A	Center Section Flap Deflector Installation (Early)	A

T-51 LANDING GEAR INDEX

LG1	T51-03-INS-0589	C	Oleo Exploded View	A
LG2	T51-03-INS-0588	B	Main Gear Leg Installation & Removal	A
LG3	T51-07-INS-1684	C	Gas Strut Extension Installation	A
LG4	T51-03-INS-0599	D	Main Gear Lock Assembly Details	A
LG5	T51-03-INS-0590	A	Main Gear Linkage Installation	A
LG6	T51-07-INS-1636	B	Main Gear Door Ins.	A
LG7	T51-04-INS-1039	C	Main Landing Gear Door Assembly Ins.	A
LG8	T51-04-INS-1036	E	Main Landing Gear Door Mounting Ins.	A
LG9	T51-05-INS-1153	C	Landing Light Mounting Ins.	A
LG10	T51-06-INS-1522	A	Complete Tailwheel Assembly	A
LG11	T51-03-INS-0816	E	Tailwheel Installation Ins.	A
LG12	T51-04-INS-1002	F	Hydraulic Cylinder Mount for Tailwheel	A
LG13	T51-07-INS-1638	A	Tailwheel Limit Switch Locations	A
LG14	T51-04-INS-1024	D	Tailwheel Door Installation	A

T-51 TAIL INDEX

T1	T51-03-INS-0862	E	Rudder Installation	A
T2	T51-05-INS-1270	A	Rudder Trim Tab Modification Ins.	A
T3	T51-05-INS-1271	A	Rudder Trim Tab Motor Ins.	A
T4	T51-05-INS-1272	A	Rudder Trim Tab Mounting Ins.	A
T5	T51-03-INS-0846	D	Elevator Installation	A
T6	T51-03-INS-0843	B	Elevator Installation	A
T7	T51-03-INS-0864	B	Fabric Rivet Layout	A
T8	T51-08-INS-1767	B	Horizontal Tip Installation	A
T9	T51-08-INS-1766	B	Elevator Tip Installation	A
T10	T51-08-INS-1768	A	Vertical/Rudder Tip Installation	A

T-51 CONTROLS INDEX

	DOC. #7	A	Flap Linkage Installation	
C1	T51-03-INS-0810	E	Control Stick Assembly	A
C1.1	T51-09-INS-1191	E	Aft Control Stick Driver Assembly	A
C2	T51-03-INS-0826	D	Push/Pull Tube Location	A
C3	T51-05-INS-1159	C	Aileron Counterweight Assembling Ins.	A

<u>LOCATION NO.</u>	<u>DRAWING NO.</u>	<u>REV.</u>	<u>DETAIL NAME</u>	<u>DRAWING STATUS</u>
C4	T51-06-INS-1496	C	Aileron Counterweight Mounting Ins.	A
C5	T51-04-INS-1082	D	Aileron Installation	A
C6	T51-03-INS-0941	D	Aileron Bellcrank Push/Pull Rod Assembly Ins.	A
C7	T51-07-INS-1583	C	Flap Motor Linkage Installation	A
C8	T51-05-INS-1287	C	Throttle Quadrant Assembly Ins.	O
C9	T51-06-INS-1392	A	Throttle Quadrant - Fwd Assembly	O
C10	T51-06-INS-1395	D	Throttle Quadrant - Aft Assembly	A
C11	T51-04-INS-1001	B	Throttle Cable & Rudder Door Cable Ins.	A

T-51 CABLE RIGGING INDEX

CR1	92-INS-0192	B	Cable Mounting Details	A
CR2	T51-05-INS-1184	D	Rudder Cable Routing Ins. #1	A
CR3	T51-05-INS-1301	E	Rudder Cable Routing Ins. #2 (Early Models)	A
CR3.1	T51-09-INS-1846	A	Rudder Cable Routing Ins. #2 (Later Models)	A
CR3.5	T51-09-INS-1827	A	Aft Rudder Pedal Cable Routing Instructions	A
CR4	T51-05-INS-1302	C	Rudder Cable Routing Ins. #3	A
CR5	T51-05-INS-1303	C	Rudder Cable Routing Ins. #4	A
CR6	T51-05-INS-1304	C	Rudder Cable Routing Ins. #5	A

T-51 HYDRAULIC INDEX

H1	T51-04-INS-1055	B	Hydraulic Brake Line Fitting Ins.	A
H2	T51-04-INS-1006	B	Hydraulic Brake Line Ins.	A
H3	T51-04-INS-1007	C	Hydraulic Brake Line Ins. (Cockpit)	A
H4	T51-04-INS-1086	B	Hydraulic Brake Line Routing (Center Section)	A
H5	T51-04-INS-1074	B	Hydraulic Brake Line Routing (Cockpit, Front Pedals)	A
H6	T51-06-INS-1520	B	Fwd Hydraulic Pump Installation	A
H7	T51-06-INS-1521	B	Aft Hydraulic Pump Installation	A
H8	T51-04-INS-0993	E	Tailwheel Hydraulic Line Ins.	A
H9	T51-04-INS-0994	C	Main Landing Gear Hydraulic Line Ins.	A
H10	T51-07-INS-1651	D	Landing Gear Hydraulic Schematic (Parker Pump)	A

T-51 ELECTRICAL INDEX

E1	T51-03-INS-0947	J	Landing Gear Electrical Schematic (Early Models)	A
E2	T51-07-INS-1650	D	Landing Gear Electrical Schematic - Simplified	A
E3	T51-05-INS-1291	A	Throttle Quadrant Micro Switch	A
E4	T51-04-INS-1114	C	Electrical Diagram - Control Lever Box	A
E5	T51-04-INS-1115	D	Electrical Diagram - Main Gear	A
E6	T51-04-INS-1116	C	Electrical Diagram - Tailwheel	A
E7	T51-05-INS-1132	B	Trim Adjustment - Front Stick	A

<u>LOCATION NO.</u>	<u>DRAWING NO.</u>	<u>REV.</u>	<u>DETAIL NAME</u>	<u>DRAWING STATUS</u>
E8	T51-05-INS-1133	B	Trim Adjustment Front/Rear Sticks	A
E9	T51-05-INS-1134	C	Flap Circuit	A
E10	T51-08-INS-1712	A	Flap Circuit Fwd/Aft Stick	A

T-51 SUPPLEMENTAL INDEX

S1	T51-07-INS-1635	B	Station #1 Center of Thrust Template	A
S2	T51-07-INS-1637	B	Station #2 Center of Thrust Template	A
S3	T51-08-INS-1692	B	Fwd Control Stick Stop Installation	A
S4	T51-07-INS-1680	B	Flap Assembly - LH & RH	A
S5	T51-02-INS-0228	C	Aileron Assembly - LH & RH	A
S6	T51-03-INS-0845	A	Vertical Stabilizer Skin & Rivet Pattern	O
S7	T51-05-INS-1223	B	Exhaust System Ins. (Cam 125)	A
S8	T51-05-INS-1209	A	Exhaust Stack Ins. (Cam 125)	A
S9	T51-06-INS-1433	C	912/914 Exhaust Manifold Installation (Early Models)	A
S10	T51-08-INS-1760	A	Filtered Air Vent Installation	A
S11	T51-09-INS-1871	A	Flap Assembly Hardware	A
S12	T51-10-INS-1874	A	Flap Bracket Stub Ribs & Flap Bracket Ins. (Late)	A
S13	T51-10-INS-1875	A	Flap Bracket Slot Layout (Late)	A
S14	T51-10-INS-1876	A	Inboard Flap Bracket Installation (Late)	A
S15	T51-10-INS-1877	A	Flap Stub Rib Installation (Late)	A
S16	T51-09-INS-1872	B	Vertical Stabilizer Fairing Installation	A
S17	T51-10-INS-1891	A	Center Section Flap Deflector Installation (Late)	A
S18	T51-10-INS-1884	A	Fiberglass Scoop Installation	A
S19	T51-08-INS-1715	D	V6 Throttle Quadrant Assembly - Fwd	A
S20	T51-10-INS-1931	A	Setting Ailerons in Neutral Position	A
S21	T51-10-INS-1932	A	Aileron P/P Rods to Driver Installation	P
S22	T51-10-INS-1936	A	Matco Non-Floating Brake Rotor Retrofit	A

T-51 OPTIONS

O1	T51-09-INS-1816	A	Dynon Auto-Pilot Installation (Elevator)	P
O2	T51-09-INS-1819	A	Dynon Auto-Pilot Installation (Aileron)	P
O3	T51-09-INS-1820	B	Rudder Aluminum Skin Installation	A
O4	T51-09-INS-1821	B	Elevator Aluminum Skin Installation	A
O5	T51-09-INS-1807	A	Elevator Bellcrank Station Stiffener	A
O6	T51-09-INS-1806	A	Turtle Deck Installation (B-Model)	P
O7	T51-09-INS-1850	A	Fuel Tank Aluminum Filler Neck Installation	A
O8	T51-10-INS-1878	A	Hyd. Brake Line Routing (Cockpit, Front & Rear Pedals)	A
O9	T51-10-INS-1890	A	Fiberglass Belly Installation	A
O10	T51-10-INS-1930	A	Aft Secondary Battery Mount Installation	A
O11	T51-12-INS-1949	A	Non-TSO Stall Warning Indicator Installation	A

<u>LOCATION NO.</u>	<u>DRAWING NO.</u>	<u>REV.</u>	<u>DETAIL NAME</u>	<u>DRAWING STATUS</u>
-------------------------	------------------------	-------------	------------------------	---------------------------

T-51 PREFLIGHT INDEX

PF1	T51-03-INS-0676 DOC. #15	C A	Weight & Balance Preflight Inspection Annual Inspection	A
-----	-----------------------------	--------	---	---